

WEICONLOCK® AN 306-00 Retaining Cylindrical Assemblies



Retaining cylindrical assemblies for bearings, shafts and bushings

Retaining cylindrical assemblies for bearings, shafts and bushings

Technische Daten

Colour	transparent
For thread connections up to	M 20 R ¾"
Gap bridging up to max.	0,15 mm
Breakaway torque	30 - 35 Nm
Prevail torque	55 - 70 Nm
Shear strength Nmm ² (DIN 54452)	25 - 35 N/mm ²
Handling strength (35 % strength)	2 - 5 min.
Final strength (100 % strength)	2-4 h
Temperature resistance	-60°C to +175°C
IMPA Code	815261
ISSA Code	75.629.07

Anaerobe Kleb- und Dichtstoffe

Surface pre-treatment

To achieve optimum results, the mounting parts should be degreased and cleaned, e.g. with WEICON Surface (roughen the surfaces, if required). WEICONLOCK can also be used on uncleaned surfaces, e.g. screws as delivered. However, the cleaner the surface, the better the results achieved.

Processing

WEICONLOCK is applied evenly straight from the Pen with the help of the dosing tip; avoid direct contact between dosing tip/metal. In the case of pressed joints and larger parts to be joined, both surfaces should always be wetted thinly and evenly. Join parts swiftly. For sliding seats, twist parts against each other when joining for optimum spreading of the adhesive. Bonded parts should not be moved until handling strength is reached. Do not pour any WEICONLOCK back into the bottle that has already come into contact with metal. Even extremely small metal particles cause the adhesive to cure inside the bottle. Therefore, in serial production, the use of dosing devices is recommended.

Storage

WEICONLOCK has a shelf life of at least 24 months, when stored at room temperature in closed original container. Protect from heat sources and direct sunlight. The air contained in the Pen keeps WEICONLOCK liquid.

Safety and health

When using WEICON products, the physical, safety-related, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Accessories

- 3070020 Activator F, 200 ml, green
- 30955172 Dosing Tip, 1 PCE

Available sizes:

- 30600020 WEICONLOCK® AN 306-00 Retaining Cylindrical Assemblies, 20 ml, transparent
- 30600150 WEICONLOCK® AN 306-00 Retaining Cylindrical Assemblies, 50 ml, transparent
- 30600200 WEICONLOCK® AN 306-00 Retaining Cylindrical Assemblies, 200 ml, transparent

Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICONLOCK® AN 306-00 Retaining Cylindrical Assemblies

WEICONLOCK®
Anaerobe Kleb- und Dichtstoffe

To the product detail
page:



Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON Middle East L.L.C. United Arab Emirates phone +971 4 880 25 05 info@weicon.ae

WEICON Czech Republic s.r.o. Czech Republic phone +42 (0) 417 532 013 info@weicon.cz

WEICON GmbH & Co. KG (Headquarters) Germany phone +49 (0) 251 9322 0 info@weicon.de

WEICON Romania SRL Romania phone +40 (0) 3 65 730 763 office@weicon.com

WEICON South East Asia Pte Ltd Singapore Phone (+65) 6710 7671 info@weicon.com.sg

WEICON Inc. Canada phone +1 877 620 8889 info@weicon.ca

WEICON Ibérica S.L. Spain phone +34 (0) 914 7997 34 info@weicon.es

WEICON Italia S.r.L. Italy phone +39 (0) 010 2924 871 info@weicon.it

WEICON SA (Pty) Ltd South Africa phone +27 (0) 21 709 0088 info@weicon.co.za

WEICON Kimya Sanayi Tic. Ltd. Şti. Turkey phone +90 (0) 212 465 33 65 info@weicon.com.tr