

Workshop Cleaner



Solvent-free and phosphate-free

WEICON Workshop Cleaner cleans and degreases all metals, plastics, types of rubber, glass, ceramics and wood. Powerfully removes grease, oil, resin, soot, wax, nicotine, insect dirt, bitumen and tar splashes. Workshop Cleaner is free of solvent, emulsifier and phosphate compatible with oil separators (ÖNORM B 5105) and, in accordance with EC-guidelines, bio-degradable. It is highly concentrated and can be diluted with water on a ratio of 1:40 (max). It contains selected foamless tensides and, in addition to manual cleaning, can be used in high-pressure cleaners, part washing machines and spray apparatuses (e.g. Pump Dispenser WPS 1500).

Characteristics

Specific properties	solvent-free, oil-separator compatible
Colour	blue
Odour	nearly odourless
suitable for processing with	WPS 1500
Minimum shelf life at room temperature	24 mon.

Thermal parameters

Temperature resistance	+5 °C to +90 °C
------------------------	-----------------

Chemical properties

AOX-free	yes
----------	-----

Approvals / Guidelines

ISSA Code	53.402.36/37/38
IMPA Code	551577/78/79

Mixing ratios

Aluminium parts	1:40
Inspection pits	1:10
Grease, soot, bitumen and tar splashes	undiluted
Chromium, stainless steel and plastic	1:30
Diesel residue	undiluted
Insect dirt	1:10
Industrial floors, forklift trucks	1:30
Hard floors	1:10
Lorries (also tarred canvases)	1:10
Machines, engines, oil/oil residues	1:10
Repair parts	1:40
Steel degreasing	1:20
Workshop equipment	1:30
Machine tools	1:30

Application

Apply Workshop Cleaner generously to the parts to be cleaned, allow to react and wipe off with a clean cloth. Repeat, if necessary. The cleaning process can be shortened by heating the product (max. +90°C). This makes it easier to remove particularly coarse soiling. Do not apply undiluted to aluminium or zinc coatings (alkaline, pH value concentrated approx. 12). Protect from frost.

Storage

Keep tightly closed in original packaging. Protect from direct sunlight. The storage temperature must not exceed +50 °C. Keep container in a cool, well-ventilated place. Store in a dry place.

Instructions for use

When using WEICON products, the physical, safety-related, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Accessories

10000393	Adapter for WSD 400, 1 PCE
10009303	Spray Set for WSD 400, 1 PCE
10009301	WSD 400 Pressurized-Air Spray Can, 1 PCE
10000398	Adjusting Valve for cans, 1 PCE
10016002	Pump Dispenser WPS 1500, 1 PCE
10016213	Extension tube for WPS 1500, 1 PCE
10000402	Pump Dispenser Special, 1 PCE

Available sizes

10016800	Workshop Cleaner, 5 L, blue
10016798	Workshop Cleaner, 10 L, blue
10053463	Workshop Cleaner, 28 L, blue
10028258	Workshop Cleaner, 1 L, blue

Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

Workshop Cleaner

Cleaners and Degreasers

To the product detail page:



Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON Middle East L.L.C.
United Arab Emirates
phone +971 4 880 25 05
info@weicon.ae

WEICON Czech Republic s.r.o.
Czech Republic
phone +42 (0) 417 533 013
info@weicon.cz

WEICON GmbH & Co. KG
(Headquarters) Germany
phone +49 (0) 251 9322 0
info@weicon.de

WEICON Romania SRL
Romania
phone +40 (0) 3 65 730 763
office@weicon.com

WEICON South East Asia Pte Ltd
Singapore
Phone (+65) 6710 7671
info@weicon.com.sg

WEICON Inc.
Canada
phone +1 877 620 8889
info@weicon.ca

WEICON Ibérica S.L.
Spain
phone +34 (0) 914 7997 34
info@weicon.es

WEICON Italia S.r.l.
Italy
phone +39 (0) 010 2924 871
info@weicon.it

WEICON SA (Pty) Ltd
South Africa
phone +27 (0) 21 709 0088
info@weicon.co.za

WEICON Kimya Sanayi Tic. Ltd. Şti.
Türkiye
phone +90 (0) 212 465 33 65
info@weicon.com.tr