

# Flex 310 M<sup>®</sup> Crystal



## Crystal-clear after curing | ISEGA-certified

WEICON Flex 310 M Crystal is transparent, strong, paintable (wet-on-wet), sandable, has an outstanding resistance to ageing and good resistance to UV rays. It contains no silicone, isocyanate, halogens or solvents. It has an ISEGA certificate and can be used as an adhesive in the food technology. Flex 310 M Crystal is an elastic adhesive suitable for bonding glass, PC\* and acrylic glass\*, metals, many plastics, ceramics, wood and stone. The product is crystal clear after curing and is particularly suited for elastic joints where the adhesive should or must not be visible. It can be used in plastic processing, metal construction, tank and apparatus engineering, in ventilation and air conditioning systems, the electrical and lighting industry, in exhibition stand construction and shopfitting, and in all applications where silicones or products containing silicones are not suitable. (\* = only for tension-free bonding)

### Characteristics

Base	1C MS-polymer	
Texture	pasty	
Colour	transparent	
Cure type	moisture-curing	
Can be painted	only "wet into the wet" within 3 h at the latest	
Stability/run-off	ASTM D 2202	1.0 mm
Building material class	DIN 4102	B 2
Minimum shelf life	at room temperature	12 mon.

### Processing

Curing condition	from +5°C to +40°C and 30% to 95% rel. air humidity	
Curing speed	in the first 24 h	2 -3 mm
Density	1,06 g/cm <sup>3</sup>	
Max. sealing joint width	25 mm	
Gap bridging up to max.	5 mm	

### Curing

Skin-over time	10 min.	
----------------	---------	--

### Mechanical properties after curing

Tensile strength	ISO 37	3 N/mm <sup>2</sup>
Elongation at break (tensile)	DIN 53504/ASTM D412	300 %
Tear resistance	DIN 53515 / ASTM D 1002	19 kN/m
Hardness (Shore A)	DIN ISO 7619	40±5
Shear strength according to DIN EN 1465		
Medium lap shear strength (DIN EN 1465/ ASTM D 1002)	2 N/mm <sup>2</sup>	
Volume change	DIN 52451	-1 %

### Thermal parameters

Temperature resistance	-40 °C to briefly +90 °C (approx. 2 h) +120 °C	
------------------------	------------------------------------------------	--

### Electrical parameters

Resistance	1,2 x 10 <sup>12</sup> Ω-m	
Specific resistance	1,2 x 10 <sup>12</sup> Ω-cm	

### Approvals / Guidelines

ISSA Code	75.509.22	
IMPA Code	812910	

### Surface Pre-Treatment

Surfaces must be clean and free of grease. Many surface soiling, such as oil, grease, dust and dirt can be removed with WEICON

Surface Cleaner. For heavily soiled metal surfaces, we recommend Cleaner Spray S; for removing old colour residues or adhesive

residues, WEICON Sealant and Adhesive Remover is ideal. Most materials can be bonded to and among each other. For certain materials or special requirements, we recommend the use of a

bonding agent (primer). Mechanical surface pre-treatment e.g. by grinding or sanding can also improve the adhesion considerably.

### Application

Application methods Cartridge gun for 310 ml cartridges, compressed air gun, we recommend a version with piston rod (WEICON Compressed Air Cartridge Gun), automatic dosing systems. Joining the components In order to guarantee and ideal wetting, the bonding parts need to be joined, before the adhesive skins over (skin-over time).

### Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON Middle East L.L.C.  
United Arab Emirates  
phone +971 4 880 25 05  
info@weicon.ae

WEICON Czech Republic s.r.o.  
Czech Republic  
phone +42 (0) 417 533 013  
info@weicon.cz

WEICON GmbH & Co. KG  
(Headquarters) Germany  
phone +49 (0) 251 9322 0  
info@weicon.de

WEICON Romania SRL  
Romania  
phone +40 (0) 3 65 730 763  
office@weicon.com

WEICON South East Asia Pte Ltd  
Singapore  
Phone (+65) 6710 7671  
info@weicon.com.sg

WEICON Colombia S.A.S  
Colombia  
Phone: +57 314 793 86 06  
Email: info@weicon.co

WEICON Inc.  
Canada  
phone +1 877 620 8889  
info@weicon.ca

WEICON Ibérica S.L.  
Spain  
phone +34 (0) 914 7997 34  
info@weicon.es

WEICON Italia S.r.l.  
Italy  
phone +39 (0) 010 2924 871  
info@weicon.it

WEICON SA (Pty) Ltd  
South Africa  
phone +27 (0) 21 709 0088  
info@weicon.co.za

WEICON Kimya Sanayi Tic. Ltd. Şti.  
Türkiye  
phone +90 (0) 212 465 33 65  
info@weicon.com.tr

# Flex 310 M<sup>®</sup> Crystal

## Ageing

The test specimens were artificially aged according to DIN ISO 21194, Annex A, to assess their long-term durability.

After artificial ageing, Flex 310 M Crystal with Primer K 200 achieved grade 1 in the bead peel test on aluminium.

Grade 1 means: more than 95% cohesive failure and less than 5% adhesive failure in the form of the adhesive peeling off the contact surface.

After artificial ageing, Flex 310 M Crystal with Primer K 200 achieved grade 5 in the bead peel test on stainless steel (V2A).

Grade 5 means: less than 5% cohesive failure.

## Storage

Store in the unopened original container at room temperature. Avoid sources of heat and direct sunlight.

## Instructions for use

When using WEICON products, the physical, safety-related, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

## Accessories

- 10025241 V-Joint Nozzle, 1 PCE
- 10059792 Pressure gun Airflow 3, 1 PCE
- 10020751 Cartridge Gun Special, 1 PCE
- 10000441 Cartridge Gun, 1 PCE
- 10101992 Clip Nozzle Green Tube, 1 PCE, transparent

## Available sizes

- 10057247 Flex 310 M<sup>®</sup> Crystal, 200 ml, transparent
- 10104017 Flex 310 M<sup>®</sup> Crystal, 280 ml (Green Tube), transparent
- 10104055 Flex 310 M<sup>®</sup> Crystal, 280 Set, transparent
- 10104246 Flex 310 M<sup>®</sup> Crystal, 280 ml (plastic bag), transparent
- 10104488 Flex 310 M<sup>®</sup> Crystal, 1 Set (10 x 280ml), transparent
- 10104970 Flex 310 M<sup>®</sup> Crystal, 280 ml (plastic bag), transparent

## Conversion table

$(^{\circ}\text{C} \times 1.8) + 32 = ^{\circ}\text{F}$	$\text{Nm} \times 8.851 = \text{lb}\cdot\text{in}$
$\text{mm}/25.4 = \text{inch}$	$\text{Nm} \times 0.738 = \text{lb}\cdot\text{ft}$
$\mu\text{m}/25.4 = \text{mil}$	$\text{Nm} \times 141.62 = \text{oz}\cdot\text{in}$
$\text{N} \times 0.225 = \text{lb}$	$\text{mPa}\cdot\text{s} = \text{cP}$
$\text{N}/\text{mm}^2 \times 145 = \text{psi}$	$\text{N}/\text{cm} \times 0.571 = \text{lb}/\text{in}$
$\text{MPa} \times 145 = \text{psi}$	$\text{kV}/\text{mm} \times 25.4 = \text{V}/\text{mil}$

To the product detail page:



### Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON Middle East L.L.C.  
United Arab Emirates  
phone +971 4 880 25 05  
info@weicon.ae

WEICON Czech Republic s.r.o.  
Czech Republic  
phone +42 (0) 417 533 013  
info@weicon.cz

WEICON GmbH & Co. KG  
(Headquarters) Germany  
phone +49 (0) 251 9322 0  
info@weicon.de

WEICON Romania SRL  
Romania  
phone +40 (0) 3 65 730 763  
office@weicon.com

WEICON South East Asia Pte Ltd  
Singapore  
Phone (+65) 6710 7671  
info@weicon.com.sg

WEICON Colombia S.A.S  
Colombia  
Phone: +57 314 793 86 06  
Email: info@weicon.co

WEICON Inc.  
Canada  
phone +1 877 620 8889  
info@weicon.ca

WEICON Ibérica S.L.  
Spain  
phone +34 (0) 914 7997 34  
info@weicon.es

WEICON Italia S.r.L.  
Italy  
phone +39 (0) 010 2924 871  
info@weicon.it

WEICON SA (Pty) Ltd  
South Africa  
phone +27 (0) 21 709 0088  
info@weicon.co.za

WEICON Kimya Sanayi Tic. Ltd. Şti.  
Türkiye  
phone +90 (0) 212 465 33 65  
info@weicon.com.tr